

Pet GPS Tracker TSB 0001
(GPS+GSM+SMS/GPRS)
User Manual Version 1.8



Thank you for purchasing the GPS tracker. This manual explains how to operate the device; read it carefully before operating the device. Please note that the specification and information contained in this manual are subject to change without prior notice; any change will be integrated into the latest release. The manufacturer does not accept liability for any errors or omissions that may be contained in this document.

I. Accessories.

Your package contains the following:

Quantity	Item
1	Pet GPS Tracker
1	Electrical plug
1	USB docking station (USB charger)
1	Screw driver
1	User manual

II. Technical data

GSM Frequency	850/900/1800/1900MHZ
GSM/GPS chip	MTK6260/MTK3337
GPRS	Class 12,TCP/IP build in GSM MODULE
GPS sensitivity	-159dBm
GPS location accuracy	5-25m
LBS location accuracy	50-200m
Speed accuracy	0.1m/Second
GPS cold start	<38 second
GPS warm start	<32 second
GPS hot start	<2 second
Maximum Elev	18,000m
maximum speed	515m/second
Weight	50g
Average standby current	<10mA
Operating temperature	-20---70°C
Humidity	20%---80%
Dimensions	56mm×36mm×16 mm (main unit)
Voltage	Rechargeable 500mAh battery
Power supply	DC5V
Standby time	>72h

III. Be prepared before start-up

1. Prepare a SIM card in tracker

- a) SIM card needs to be GSM Network;
- b) SIM card needs to have Caller Identification function;
- c) SIM card needs to have GPRS function;
- d) SIM card needs to have SMS function;

Important note: Please turn power off before installing or removing the SIM card;




2. Switch on the device:

Plug the device into the USB docking station to switch it on automatically.



3. Switch off the device: (for non-charging status only)

SMS text command: **shutdown#**



4. Charging Status

a) Starting charging: When the device starts to charge, the orange and blue LED will continually blink.

b) Fully Charged: When fully charged, the orange light will blink every 2 seconds.


Quick start-up

1. Set up the administration number. This is the phone number the tracker will accept commands from. To setup the administration number, simply send the following SMS message to the tracker's mobile number from your mobile phone: SMS Template:

pw,123456,center,<the_administration_phone_number>#

Example:pw,123456,center,008618676389718#

If successful, the device will reply with: center:008618676389718. ok!



2. Set up your time zone.


SMS Template:lang,0,zone,<time_zone>#

where <time_zone> is the time difference to GMT.

For example to set up China time zone, send the following message:


lang,0,zone,+8#

When successful, the device will reply with:[lang,0,zone,+8#] ok!



3. To check the status and all information of the device, please send below command

test#




4. To check your GPS tracker is operating correctly, send the following SMS to the tracker's number:

SMS Template:

url#

The tracker will reply by SMS with a link. Simply select the link and your phone's map program will open to show the current location of the device.



5.If you intend to use the mobile App or the platform, then you may need to set the APN. You probably won't need to set this as most networks will provide a SIM which automatically allows access.

a) Please refer to test# reply, if GPRS:OK, that means APN no need to set.

```
GPRS:OK(100);  
LED:ON;  
pw:123456;
```

b) If GPRS:NO, that means APN need to set. Contact your network provider for the APN name.


```
GPRS:NO(93);  
LED:ON;  
pw:123456;
```

*SMS Template: **apn,apn name,user,password,#***

For example, if you are using a SIM card from China Unicom, the APN is '3gnet' and does not require a user name nor password. You should send the following command:

apn,3gnet,,,#

You will get SMS reply as below as long as the format is correct.




After the APN is set, please resend command of test# to check if GPRS is OK. If still NO, please double confirm with your network provider.



6. Low battery alarm:

When the battery level reaches less than 20%, the device will send a low power alert SMS text to the center number (3 times).



IV. Commands summary

The following are commands that you can send to your GPS tracker using SMS. The tracker will process the request and reply accordingly. Note that the commands should be sent using the exact case (lower or uppercase) as in the table below:

Description	SMS template	Example
Set up an administration phone number	pw,123456,center,<the_administrati on_phone_number>#	pw,123456,center,008618 676389718#
Change the default password (a) (<i>see below</i>)	pw,<new_password>#	pw,888888#
Set up an auxiliary administration phone number	pw,123456,slave,<the_administrati on_phone_number>#	pw,123456,slave, 008618676389718#
Set up the time	lang,<language_id>,zone,<time_zo ne>#	lang,0,zone,-0#
Check the tracker's settings	test#	test#
Request the tracker's current position	url#	url#
Set up the tracker for use with Mobile App and the internet	apn,<mobile_network_apn>,<apn_ user_name>,<apn_password>#	apn,data.xyz.com#
Change the tracker's operation mode (b)	m<mode_number>,<upload_interv al_in_seconds>#	m2,600#
Change the data upload time interval (b)	upload,<upload_interval_in_second s>#	upload,300#
Restart the tracker	reset#	reset#
Restore factory settings	factory#	factory#
Set a different platform server	ip,<ip_address>,port,<port_number >#	ip,59.188.20.67,port,7018 #

- a) The default password is 123456. The new password has to be 6 digits long.
- b) There are four modes of operation, so <mode_number> varies from [1-4] depending on the mode you wish to select. The <upload_time_interval> is expressed in seconds and varies from [10-65535] seconds.

Mode 1 – (Command: m1,10#) – Default Working Mode. GSM and GPS are active, the device will send GPS data to the server every 10s (10#). (10s to 65535s, default 10s).

Mode 2 – (Command: m2,600#) – Power saving mode. Device sleeps, but turns on GPS and sends the data to the server at set intervals (Minimum 600s).

Mode 3 – (Command: m3,20#) – LBS (Location Based Service) mode. GPS is switched off; the device uses its closest mobile network tower to determine a (less accurate) location.

Mode 4 – (Command: m4#) – Sleep Mode. Always sleeps unless woken up by calling or SMS text. It can send a Google Maps link by SMS.

V. Using the mobile App

The Android app can be downloaded by scanning the QR code below:



For iOS, use this QR code:



VI. Using the platform

Platform website: <http://www.track188.com/>

Use the ‘test#’ command to find out your device ID. Unless you have changed it, the default password is ‘123456’.